

MB1440 – MicroBlaster® Tune-Up Parts Kit

Establishing and following a regularly scheduled maintenance program on your equipment reduces costly downtime and increases productivity. Enclosed you will find the parts required to perform a routine Tune-Up on your MicroBlaster® abrasive machine. Should you have any questions about performing your own maintenance give our Technical Support department a call at 1-800-796-6626.



MB1230-1 – Nozzle Nose (1)



MB1301-2 – Modulator Housing Assembly (1)



MB1455 – Connector with QuickNut (2)



ST5022 – O-ring (1)
(4.109ID x .139THK)



ST4020 – 1/4" Ferrule (5)



ST4019 – 1/4T Brass Nut with Sleeve (2)




MB1233 – 1/4" Abrasive Tube
(25 feet)



ST4012 – 1/4" Nylon Tube
(3 feet)



ST5624 – O-ring (1)
(2.00ID x .139THK)



TS010 – MB1440 Tune-Up Kit
Instructions (1)

Want to get the most from your MicroBlaster®? You can review technical bulletins on everything from modulator maintenance to the importance of clean, dry air, or access Comco's complete library of documents on specific micro-abrasive blasting applications. Download this informative literature—and more—directly from our website at www.COMCOinc.com, or call Customer Service today!



COMCO INC. 2151 N. Lincoln St. / Burbank, CA 91504
818-841-5500 / 800-796-6626 / www.comcoinc.com